Assignment 1

* Different types of Cables

1 Copper Straight Through Cable ->

- · Description -> A copper stronght-through cable is perhaps one of the most commonly used metrook cables. It's characterisqued by the same pin configuration at both ends, meaning the wirres in the cable are connected straight through from one end to the other. It connects two different types of devices.
- · Use-Cases -> :> Connecting a PC to a switch on hub, between different retwork segments.

2 Copper Crossover Cable -

- Description -> Copper conssover cables, on the other hand, feature different pin configurations at each end. These cables and designed for connecting similar devices directly to each other, bypassing the need for intermediary rebronking
- · Use-Cases > :> connecting two PCs directly without a switch or hub. is a consisting a direct link between two switches for medundancy or high-speed interconnection.

3> Fiber-Optic Cable ->

- · Description > Fiber-Optic cables Stand out in the world of networking for their use of light signals instead of electrical signals. They often high bandwidth, immunity to electronnagnetie interference & extended trounsmission distances.
- · Use Cases -> i) High speed, long-distance connections in data centers & telecommunications,
 - Environments with high levels of electromagnetic inter ferrence.

A Connection Between Similar Systems

In Cisco networking, when connecting two similar devices, a coppen crossover cable is used to ensure proper communication. The key concept behind this is the T568A & T568B wiring standards, which define how the pins are arranged in the RJ45 connectors.

• When to Use a Crossover Cable?

A Crossover cable is used when connecting similar devices, such as: i) Switch to Switch

ii) Router to Router

iii) PC to PC

iv) Hub to Hub


This is necessary because similar devices transmit & receive data on the same pins. A crossover cable swaps the transmit (Tx) & receive (Rx) pairs, enabling prooper communication.


Example -> In the given example shown in the printout ->
i) First I have connected two PCs with the help of
copper crossover cable.

ii) Then I have configured the IP statically on the both systems.

Then using the "ping" command from the command prompt—
I have pinged / sent packets & got the roeply from other system.

"V Attest using "app -a" command I have displayed the Internet address of physical address of the necessiver device.





* Switch & Server

a) Switch - A switch is a networking device that operates at Data link layer of the OSI model of is used to connect multiple devices within a LAN. It forwards data based on MAC addresses, ensuring efficient communication within the network.

· Key Features: ~?

i) MAC address learning & forwarding.

ii) VLAN support for network segmentation.

iii) Spanning Troce Porotocol for loop proevention,

iii) Spanning Troce Porotocol for loop proevention,

iv) Layer 3 Switching (In some advanced models).

Server A server roefers to a system that provides roesources, services, or applications to clients within the network. It can be a DNS server, DHCP server, Web server, File Server etc. Servers are crucial for centralized management & ensuring smooth network operations.

· Key Features: >

? Provides services like file sharing, authentication

il) Can be connected to a switch for client-

in/ Requires IP addressing (Static or DHCP-assigned)

* Connection Between Two Different Systems

A copper straight - through cable is used to connect different types of networking devices because it follows the same wiring standard on till of Standard on both ends (T568A to T568A on T568B to T568B). This ensures proper data transmission between devices that communicate on different Tx/Rx pairs.

- · When to use a copper Straight-through cable?
- -> A copper Straight-through cable is used when connecting different devices, such as: > :> PC to switch, in To to mouter, in Switch to souter. ive thub to nuter, etc.
- Example -> In the given example shown in the printout-> ip first I have connected two PCs are laptop of one Server using a switch (PT switch 4 chammed) with copper stroaight through cable between PC & switch, Laptop & Switch & between the server of switch.

in Then I have configured the IP addresses statically on every system.

- iii) Then opening command prompt I have pinged the two PCs & the server from the laptop & sent packets & got soeff from the other systems.
- iv) Atlast using "amp -a" command I have displayed all the internet addresses & physical addresses of all other receiver devices.

